

IT

Norme di sicurezza

- Utilizzare il dispositivo solo per gli scopi previsti e conformemente alle istruzioni del manuale.
- Evitare l'uso in ambienti estremamente umidi, polverosi o con temperature estreme. Non utilizzare il prodotto vicino all'acqua o in luoghi umidi per prevenire malfunzionamenti o scosse elettriche.
- Assicurarsi che i cavi non siano danneggiati, attorcigliati, schiacciati o sottoposti a trazione eccessiva. Non tirare il cavo per scollegarlo dalla presa.
- Non posizionare oggetti pesanti sui cavi o sul dispositivo. Posizionare il dispositivo su superfici stabili e orizzontali per evitarne la caduta o il danneggiamento.
- Non collegare più dispositivi alla stessa presa elettrica per evitare sovraccarichi. Utilizzare solo prese e adattatori conformi agli standard locali e dotati di messa a terra.
- Tenere i cavi e il dispositivo lontano dalla portata di bambini e animali domestici per prevenire rischi di strangolamento, masticazione o uso improprio.
- Non inserire oggetti o liquidi nelle aperture del dispositivo o nei connettori dei cavi per evitare cortocircuiti, incendi o scosse elettriche.
- Controllare periodicamente lo stato dei cavi per verificare eventuali segni di usura o danni. Sostituire immediatamente i cavi danneggiati.
- Le aperture di aerazione devono rimanere libere per garantire la ventilazione e prevenire surriscaldamenti.
- Durante i temporali o in caso di inutilizzo prolungato, scollegare il dispositivo dalla rete elettrica per prevenire danni da sovratensioni.
- Non smontare, riparare o sostituire parti del dispositivo. Le riparazioni devono essere eseguite esclusivamente da centri di assistenza autorizzati.
- Smaltire il prodotto e le batterie in conformità alle normative locali sul riciclaggio dei rifiuti elettronici.

Pulizia del dispositivo

- Scollegare il dispositivo dalla corrente prima di pulirlo. Utilizzare un panno asciutto per la pulizia esterna. Non utilizzare liquidi, prodotti spray o detergenti aggressivi.

Sostituzione della batteria

Alcuni dispositivi possono contenere batterie interne che richiedono particolare attenzione:

- Non esporre le batterie a temperature superiori a 60°C o a fonti dirette di calore.
- Non smontare, ricaricare, perforare o gettare le batterie nel fuoco o nell'acqua.
- Sostituire le batterie solo con modelli conformi e raccomandati dal produttore.
- Smaltire le batterie secondo le normative locali, utilizzando i sistemi di raccolta dedicati.

Danni all'udito

- L'uso prolungato di cuffie o auricolari ad alto volume può causare danni permanenti all'udito. Limitare il tempo di utilizzo a volumi elevati e abbassare il volume se non si percepiscono suoni o voci nelle vicinanze.

Avvertenze generali

- Non collocare il prodotto vicino a fonti di calore, esposizione diretta ai raggi solari o apparecchiature che emettono campi elettromagnetici intensi (es. televisori, motori elettrici, trasformatori).
- Non intervenire personalmente sui componenti del dispositivo. Per aggiornamenti o riparazioni rivolgersi al rivenditore o a personale autorizzato.
- Oggetti piccoli o parti della confezione possono rappresentare un rischio di soffocamento: conservare il prodotto e la confezione lontano dalla portata dei bambini.
- Assicurarsi che il cavo di alimentazione sia collegato correttamente a una presa CA stabile e accessibile.

Avvertenze relative ai cavi

- Non avvolgere i cavi attorno al dispositivo o piegarli in modo eccessivo per evitare danneggiamenti.
- Evitare che i cavi siano a contatto con superfici calde o taglienti.
- Quando si scollega un cavo, afferrare sempre la spina e non tirare direttamente il cavo.
- Mantenere i cavi in ordine per evitare che possano rappresentare un rischio di inciampo.

Epilepsy Warnings

- Viewing images with particularly intense or flashing lights, such as during video games or multimedia content, may trigger seizures or loss of consciousness in individuals predisposed to epilepsy.
- These symptoms can also occur in people without a prior history of epilepsy. If you experience dizziness, vision problems, muscle or eye twitching, loss of consciousness, disorientation, involuntary movements, or seizures, stop using the device immediately and consult a doctor.
- Parents are advised to closely monitor their children's behavior while using the device and to stop its use immediately if any of the above symptoms occur.

ENG

Safety Instructions

- Use the device only for its intended purposes and in accordance with the instructions in the manual.
- Avoid using the device in extremely humid, dusty, or high-temperature environments. Do not use the product near water or in damp areas to prevent malfunctions or electric shocks.
- Ensure that cables are not damaged, twisted, crushed, or subjected to excessive tension. Do not pull the cable to disconnect it from the socket.
- Do not place heavy objects on cables or the device. Place the device on stable, horizontal surfaces to prevent falls or damage.
- Do not connect multiple devices to the same power outlet to avoid overloading. Use only outlets and adapters that comply with local standards and are equipped with grounding.
- Keep cables and the device out of reach of children and pets to prevent risks of choking, chewing, or misuse.
- Do not insert objects or liquids into the device openings or cable connectors to avoid short circuits, fires, or electric shocks.
- Periodically inspect the cables for signs of wear or damage. Replace damaged cables immediately.
- Keep ventilation openings clear to ensure proper airflow and prevent overheating.
- During thunderstorms or prolonged periods of inactivity, disconnect the device from the power supply to prevent damage from power surges.
- Do not disassemble, repair, or replace parts of the device. Repairs must be carried out exclusively by authorized service centers.
- Dispose of the product and batteries in compliance with local electronic waste recycling regulations.

Cleaning the Device

- Disconnect the device from the power supply before cleaning. Use a dry cloth for external cleaning. Do not use liquids, sprays, or aggressive detergents.

Battery Replacement

Some devices may contain internal batteries that require special care:

- Do not expose the batteries to temperatures above 60°C or direct heat sources.
- Do not disassemble, recharge, puncture, or dispose of batteries in fire or water.
- Replace batteries only with models recommended by the manufacturer.
- Dispose of batteries in compliance with local regulations, using designated collection systems.

Hearing Damage

- Prolonged use of headphones or earphones at high volumes can cause permanent hearing damage. Limit usage time at high volumes and lower the volume if you cannot hear sounds or voices nearby.

General Warnings

- Do not place the product near heat sources, direct sunlight, or devices emitting strong electromagnetic fields (e.g., televisions, electric motors, transformers).
- Do not attempt to repair the device yourself. For updates or repairs, contact an authorized dealer or service personnel.
- Small objects or parts of the packaging can pose a choking hazard: keep the product and packaging out of reach of children.
- Ensure the power cable is properly connected to a stable and accessible AC outlet.

Cable-Related Warnings

- Do not wrap cables around the device or excessively bend them to avoid damage.
- Prevent cables from coming into contact with hot or sharp surfaces.
- When unplugging a cable, always hold the plug and avoid pulling directly on the cable.
- Keep cables organized to prevent tripping hazards.

Epilepsy Warnings

- Viewing images with particularly intense or flashing lights, such as during video games or multimedia content, may trigger seizures or loss of consciousness in individuals predisposed to epilepsy.
- These symptoms can also occur in people without a prior history of epilepsy. If you experience dizziness, vision problems, muscle or eye twitching, loss of consciousness, disorientation, involuntary movements, or seizures, stop using the device immediately and consult a doctor.
- Parents are advised to closely monitor their children's behavior while using the device and to stop its use immediately if any of the above symptoms occur.